



Dell XPS 1340 CPU Fan Replacement

Replacing the stock CPU Fan with spare

Written By: Paras Tolani



Step 1 — CPU Fan




- Remove the battery by sliding the battery lock switch

Step 2




- Remove the lower panel of the laptop by loosening 10 screws. Note that the screws do not come out of the back panel.

Step 3




- Remove two screws which holds a smaller back panel covering only the heatsink

Step 4




- Loosen the four screws on the heat sink for the CPU. Note that these screws don't come out.
- Now carefully lift the unit from holding the heat pipe.
- After the heat-pipe unit is removed, the power connector for the fan is accessible.

Step 5



- First remove the power connector for the CPU Fan.
- Now remove the two screws connecting the CPU Fan.
- ⓘ Slowly slide the CPU Fan upwards. It would be a little tight around the edges.

Step 6



- ★ ☒ Unpack the new fan. Make sure the power wires are fixed in the hook provided.

Step 7



- Follow all step backwards and finish.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-07 02:07:43 PM.